

Protective Features

1. Automatic cutoff: After ten seconds the device will cease firing and the LED light will flash either blue or orange ten times. If the K4 is above 3.5 Volts charge the light will be blue, if the K4 is below 3.5 Volts the light will be orange.
2. Short circuit protection: If the K4 detects a short circuit the device will immediately cease firing and the light will flash both blue and orange two or three times.
3. Low voltage protection: When the K4's charge drops to 3.2 volts the LED will flash orange fifteen times and the device will stop functioning.
4. Overcharge protection: When the battery has fully charged to 4.2 volts the K4 will automatically stop charging.

Specifications

1. K4 tank capacity: 3.5ml
2. K4 atomizer: Kanthal Clapton 0.27 Ohm, 40-55 Watts(preinstalled)
3. K4 battery capacity: 2000mah
4. Bypass output

Charging Instructions

While charging the K4's LED will shine red, when the voltage reaches 4.2 the LED on the bottom will turn green to indicate that your K4 is fully charged.



aspire®

User manual for K4 Quick Start kit

Thank you for choosing the Aspire K4 Quick Start kit. This simple and convenient kit just needs ejuice and you're ready to go. The K4 kit features usb charging and a refillable tank. Using Aspire's Bottom Vertical Coil technology the K4 will give you an amazing direct to lung experience with flavor that no cigarette can match.

Instructions

1. Pressing the fire button five times within two seconds will turn on or off the K4 battery. The fire button will flash blue and orange three times to indicate off or on..
2. When the K4 is in use the light on the button will indicate your K4's current charge. When the K4's current charge capacity is above 3.5 volts the fire button will shine blue. When the charge drops below 3.5 volts the light will then become orange to remind you that it is time to charge your K4.

