



# iJust D14 Battery User Manual

## Notice for Use

Thank you for choosing Eleaf products! Please read this manual carefully before use so as to use correctly. If you require additional information or have questions about the product or its use, please consult your local agents, or visit our website at [www.eleafworld.com](http://www.eleafworld.com).

## Product Introduction

iJust D14 Battery features the adjustable voltage from 3.3V to 5V and maximum output 10 watts which can offer you a strong vaping experience. Furthermore, elegant appearance with smooth touch; 650mAh/900mAh battery capacity for your option, tail LED digital screen which can show you current voltage, total puffs, vaping seconds. All these insure you a fantastic vaping experience.

## How to use

**Power on and off:** Press the button for 5 times in quick succession, the button light will flash 5 times to indicate iJust D14 is ready for use. The tail LED digital screen will show the current power. In the same way, iJust D14 will be powered off after 5 presses.

**Vape:** Long press the button while inhaling the mouthpiece lightly to get a puff. The tail LED digital screen will show the increasing vaping seconds. When you loosen the button, the total vaping seconds will be displayed for 0.5 seconds. After that, the tail LED digital screen will show the current power for 3 seconds.

**VV mode (3.3V-5V):** In this mode, voltage output can be adjusted by rotating the regulation ring clockwise or counterclockwise. The tail LED digital screen will show the current voltage during adjusting.

**Charging:** Plug the USB cable to the iJust D14, and connect it to the wall adaptor or other power source such as a computer. (it can be used whilst on charge)

(During charging, the "%" symbol on the bottom of battery will keep flashing and stop flashing when fully charged)

## Properties

**Over-current Protection:** When over-current protection occurs, the vaping seconds on the LED digital screen will stop increasing. Two seconds later, the LED digital screen will show the current voltage for five seconds. At the same time, the button light will flash five times.

**Short-circuit Protection:** When short-circuit occurs, the battery will shut off automatically.

**Low-voltage Protection:** When the voltage of battery is below 3.3V, the button light will flash 40 times. At the same time, the LED digital screen will go out.

**Unlock the Low-voltage Protection:** When the voltage of battery is above 3.65V, the low-voltage protection will be unlocked.

## Precautions

1. Only have your iJust D14 repaired by Eleaf. Do not attempt to repair the unit by yourself as damage or personal injury may occur.
2. Do not leave the iJust D14 in high temperatures or damp conditions, otherwise it may be damaged. The appropriate operation temperature is within 0°C to 45°C while charging and -10°C to 60°C while using.
3. Do not attempt to combine the iJust D14 with parts from other brands of e-cigarettes. If it is damaged in this way, our company will not take on responsibility and your warranty will be void.

## Warranty

Please consult your Eleaf product warranty card. We are not responsible for any damages caused by human error. Our warranty is not available for products purchased from third-party vendors.

Email: [info@ismoka.com](mailto:info@ismoka.com)  
Web: [www.eleafworld.com](http://www.eleafworld.com)



MADE IN CHINA

Manufactured by iSmoka