

Introduction

R40 Kit is made up of the R40 temperature control box mod and Micro Basic Tank. Featuring 40 watts maximum output, compact and stylish design, R40 is a beauty of a pocket sized device! It takes a 1900 mAh internal battery and with a Micro-USB port on the bottom for charging and firmware upgrading. Micro Basic Tank features two cores: 1.2Ω Micro MTL Single Clapton Core and 0.6Ω Fused Clapton Dual Core. R40 kit will provide you the best taste at unbeatable great prices. Innovation keeps changing the vaping experience!

The Kit Includes

1xR40 TC Box Mod (40w)	1xMicro Basic Tank (22mm)	1
1x 0.6Ω Fused Clapton Dual Core (Pre-installed)	1xSMOK Vape Band	
1x1.2Ω Micro MTL Single Clapton Core	1xUser Manual	
1xUSB Charging/Upgrading Cable	Spare Parts	

Specifications

R40		
Size: 75x38x22 mm	Weight: 108 g	
Material: Aluminum Alloy and Zinc Alloy	Battery Capacity: 1900mAh	
Power Range: 1W-40W	Voltage Range: 0.8V-9V	
Charging Voltage and Current: 5V 1A	Standby Current: < 50μA	
Input Current: Minimal 1A, Normal 10A, Maximum 30A		
Temperature Range: 200°F-600°F/ 100°C-315°C		
Resistance Range: 0.06Ω—2.0Ω (TC Mode)		
0.1Ω—3.0Ω (VW Mode)		
Micro Basic		
Material: Glass & Stainless Steel	Weight: 52.7 g	
Dimension: 22mm x 52mm	Thread: 510	
Capacity: 2.8ml		2

User Guide


Warning:Please read the user manual careful and ensure the batteries you used according with the battery warning card before use.
Note:This is the simplified user manual, please visit SMOK official website: www.smoktech.com for complete version. Moreover, your first language user manual is available via language selection.

Menus

After starting up, fast press the Power Button 3 times, the screen will display as follows:

	Menu		Screen Direction	3
	Coil Type		TCR	
	HARD/NORM/SOFT		ADJ OHM	
	SCR TIME		POWER ON/OFF	
	Vape Data		Unlock/Lock	

Components



Tank Operation Guide

1.E-liquid Filling

1)Hold the tank with one hand, and use another one to screw off the top cap and drip tip.



2)Add e-liquid through three slots, and pay attention not to drip it into the central airflow tube.



3) Close the cap carefully and firmly. Then let it stand for several minutes to get the organic cotton completely saturated.



2. Atomizer Core Replacement

Firstly, screw the base part off the tank; then screw the atomizer core off the base part, and replace with a new one.



3. Air Control

Rotate the adjustable airflow ring to control air input.



Attentions

- 1.Before use please read the manual carefully.
- 2.Before installing atomizer, please make sure the air drain cannot be blocked in case of feeling suffocated when you are vaping.
- 3.Please do not keep the liquid inside the atomizer if the device is not going to be used for a long period.
- 4.Please refill the tank when the e-liquid is nearly used out to avoid dry-burning of the atomizer.
- 5.Please do not drop, throw or mishandle this product as the outer shell or inner components may become damaged.
- 6.In order to prolong the operation of your product, please keep it away from excessive temperature and humid environment.
- 7.Please keep this product away from children and pregnant women.

